

ATT 2767 (2767 ISO-B)

CHEMICAL ANALYSIS (PERCENTAGE BY MASS)

	С	Si	Mn	P	S	Cr	Ni	Мо
Guide analysis	0.45	0.25	0.30	0.025	0.003	1.30	4.00	0.25
Standard	0.40-0.50	0.10-0.40	0.20 - 0.50	≤ 0.030	≤ 0.030	1.20-1.50	3.80-4.30	0.15-0.35

CHARACTERISTICS

Low-distortion, air through-hardened nickel alloy tool steel with extremely good toughness; polishable, grain-reliable.

APPLICATION

Highly stressed compression and injection molds such as tailgates, mudguards; mold inserts for high hardening and abrasive stress. Blanking dies for very thick materials (sheet steel up to 12 mm thick), billet shearing blades, industrial blades. Cutlery presses and stamping dies, forging dies, mandrel holders for extrusion mandrels.

DELIVERED CONDITION

Annealed to max. 285 HB Contour hardening is recommended for large molds

PHYSICAL PROPERTIES

Thermal Conductivity (W/m.K) at	20°C 31.0	250°C 30.0	500°C 32.0
Thermal Expansion (µm/m)	100°C	250°C	500°C
from 20°C to	11.0	12.2	13.7
Vound's modulus (CDs)	20°C	250°C	500°C
Young's modulus (GPa)	215	198	179

45NiCrMo16 DIN EN ISO 4957 AFNOR 45NCD16

6F7

Advanced Tooling Tek Shanghai Co., Ltd.

No, 1-3, Lane 499, Xin Miao San Road, Xianqiao Town, Songjiang Dist., Shanghai, 201612 China Tel: +86 21 3373 8146 | Fax: +86 21 3373 8193 | info@att-metal.com







ATT 2767 (2767 ISO-B)


HEAT TREATMENT

Stress relieving	Temperature Duration	Approx. 600°C in the quenched and tempered state 1 hour per 50 mm wall thickness Furnace			
	Cooling Temperature	650°C			
Soft annealing	Duration	1 hour per 25mm wall thickness			
	Cooling	Furnace			
Hardening	Temperature	870°C			
пагиеннія	Duration	1 min per mm wall thickness			
Quenching hardness	Max. 56 HRC	in oil, hot bath, air or vacuum			
	Temperature	See tempering curve			
Tempering	Duration	1 hour per 25 mm wall thickness			
	Cooling	Air			
Working hardness	50-54 HRC	temper at least twice 220°C			


Note: If soft annealing is required: do not exceed annealing temperature, hold at temperature for the full annealing time!

In the case of oil hardening, do not leave tools to cool down in the oil.

Tempering curve



TTT curve (continuous)



Page2/2